



Working Together to Solve your Material Handling Needs

CPP 333 Plastic Pallet: 3-Runner Version

Step 1 Lay the CPP 333 plastic pallet face down on a hard flat surface. (Fig 1)



Fig 1

Step 2 Align the 3 bottom runners with the skid blocks by laying it on top of the blocks, snap side facing the blocks. (Fig 2)



Fig 2

Step 3 Secure a 2" x 4" x 4' piece of wood or other suitable object. If you have two people, the second person can apply the needed pressure with their foot.



Fig 3

Step 4 Apply pressure with your foot on the bottom runner by leaning on the middle of the span between two blocks. (Fig 3)

Step 5 Starting with the center blocks, use the 2x4 or a foot and firmly press or tap on top of block until the bottom runner snaps into place. (Fig 4)



Fig 4

Step 6 Repeat step 5 until all three joints are secure. (Fig 5)

Note: Occasionally 1-2 of the tabs will snap off. This should not affect the carrying capacity of the pallet.



Fig 5

[View Our Complete Line Of Plastic Pallets](#)